



load Stop on tubing:

- 1, Insert tweezers into the stop
- 2, Open the tweezers to enlarge the hole of the stop.
- 3, Insert tubing into the hole of stop.
- 4, Take the tweezers from the hole of stop.

