


## T300-SX Specification

### 1 Product Model

| Product Model | Description                                                    |
|---------------|----------------------------------------------------------------|
| T300-SA       | Speed control through BCD dial switch or 4-20mA current signal |
| T300-SV-05    | Speed control through BCD dial switch or 0-5V voltage signal   |
| T300-SV-10    | Speed control through BCD dial switch or 0-10V voltage signal  |
| T300-SF       | Speed control through BCD dial switch or 0-10kHz pulse signal  |
| T300-SC       | RS485 communication control                                    |



### 2 Main Features

- CE certified with good EMC performance
- Meet RoHS 2.0 requirement
- Low vibration and low noise

### 3. Main Function

#### 3.1 T300-SA, T300-SV-05, T300-SV-10, T300-SF Main Function

- 3.1.1 Two control modes for pump speed control:
  - Control the speed through BCD dial switch.
  - Control the speed through current, voltage or pulse signal.
- 3.1.2 Start/stop can be controlled by external switch signal: pump runs when switch is open, pump stops when switch is closed.
- 3.1.3 Running direction can be controlled by external switch signal: CW when switch is open, CCW when switch is closed.
- 3.1.4 Applicable pump head options: YZ1515x, YZ2515x, YZII15, YZII25, FG15, FG25, BZ15, BZ25, etc.

### 3.2 T300-SC Main Function

- 3.2.1 Start/stop, running direction and speed are controlled through serial communication with RS485 interface.
- 3.2.2 Prime function also can be carried out through RS485 communication, to run pump at full speed for fast filling or emptying.
- 3.2.3 DIP switch is for communication address and baud rate setting.
- 3.2.4 Power-off memory function stores the running parameters automatically.
- 3.2.5 Pump is controlled via Longer OEM protocol or Modbus protocol
- 3.2.6 Applicable pump head options: YZ1515X, YZ2515X, YZII15, YZII25, FG15, FG25, BZ15, BZ25, etc.

## 4 Technical Spec

### 4.1 T300-SA, T300-SV-05, T300-SV-10, T300-SF Specification

- 4.1.1 Pump speed: 0-300rpm
- 4.1.2 Speed resolution controlled by external signal: 1rpm
- 4.1.3 Speed corresponding to BCD dial switch position 1-F: 5, 10, 20, 40, 60, 80, 100, 125, 150, 175, 200, 225, 250, 275, 300rpm
- 4.1.4 Power supply: DC 24V
- 4.1.5 Power consumption:  $\leq 50W$
- 4.1.6 Working condition: temperature 0-40°C, relative humidity <80%, no condensation

### 4.2 T100-SC Specification


- 4.2.1 Pump speed: 0-300rpm
- 4.2.2 Speed resolution: 1rpm
- 4.2.3 Power supply: DC 24V
- 4.2.4 Power consumption:  $\leq 50Ws$
- 4.2.5 Working condition: temperature 0-40°C, relative humidity <80%, no condensation

## 5 Applicable Pump Head and Tubing, and Reference Flow Rate

| Applicable Pump Head        | Silicone Tubing                   | Reference Max Flow Rate<br>(silicone tubing)<br>mL/min | Pharmed Tubing     |
|-----------------------------|-----------------------------------|--------------------------------------------------------|--------------------|
| YZ1515x(3 rollers), YZ II15 | 13#, 14#, 19#, 16#, 25#, 17#, 18# | 1140                                                   | 13#, 14#, 19#, 16# |
| FG15-13                     | 13#,14#,19#,16#,25#               | 690                                                    | 13#, 14#, 19#      |
| DMD15-13-B<br>DMD15-13-D    | 2*13#,2*14#,2*19#, 2*16#,2*25#    | 1040                                                   | 2*13#, 2*14#       |
| BZ15-13-A                   | 14#                               | 80                                                     | 14#                |
| BZ15-13-B                   | 16#                               | 240                                                    | 16#                |
| BZ15-13-C                   | 25#                               | 470                                                    | 25#                |
| BZ15-13-D                   | 17#                               | 840                                                    | Not Recommended    |
| BZ25-13-B                   | 24#                               | 800                                                    | Not Recommended    |
| DG15-24                     | 16#, 25#, 17#                     | 900(Single Channel)                                    | Not Recommended    |
| YZ2515x , YZII25            | 15#, 24#                          | 840                                                    | Not Recommended    |
| FG25-13                     | 15# 24#                           | 1100                                                   | Not Recommended    |

Note: The flow rate in above table is only for the reference, which were tested at the indoor temperature with water. When select pump head and tubing, the decay of flow and the fluid viscosity need to be considered.

## 6 Installation Dimension



## 7 Hardware Setting and Terminal Instruction

### 7.1 T300-SA, T300-SV-05, T300-SV-10, T300-SF Hardware Setting and Terminal Instruction

#### Terminal Instruction

| Wiring Terminal | Definition                             | Wiring Terminal | Definition        |
|-----------------|----------------------------------------|-----------------|-------------------|
| 1               | 24VDC Power Supply -                   | 6               | Start/Stop Signal |
| 2               | 24VDC Power Supply +                   | 7               | CW/CCW Signal     |
| 3               | Common Grounding of CW/CCW, Start/Stop | 8               | Pulse Signal +    |
| 4               | Current or Voltage Signal -            | 9               | Pulse Signal -    |
| 5               | Current or Voltage Signal +            |                 |                   |



## BCD Dial Switch Position vs Speed

| BCD Dial Switch Position | Speed (RPM)                            |
|--------------------------|----------------------------------------|
| 0                        | Speed is Controlled by external signal |
| 1                        | 5                                      |
| 2                        | 10                                     |
| 3                        | 20                                     |
| 4                        | 40                                     |
| 5                        | 60                                     |
| 6                        | 80                                     |
| 7                        | 100                                    |
| 8                        | 125                                    |
| 9                        | 150                                    |
| A                        | 175                                    |
| B                        | 200                                    |
| C                        | 225                                    |
| D                        | 250                                    |
| E                        | 275                                    |
| F                        | 300                                    |

### 兰格恒流泵有限公司

地址：保定国家高新技术产业开发区大学科技园6号楼B座3-4层  
电话：+86-312 3138553 3132333  
传真：+86-312 3168553  
邮箱：info@longerpump.com

### Longer Precision Pump Co., Ltd

Add: 3rd/4th Floor, Building 6B, University Science Park  
Baoding National, High - Tech Industrial Development Zone  
Baoding, Hebei, China 071051  
Tel: +86-312-3110087 Fax: +86-312-3168553  
Email: longer@longerpump.com

## 7.2 T300-SC Hardware Setting and Terminal Instruction

### Terminal Instruction

| Wiring Terminal | Definition             |
|-----------------|------------------------|
| 1               | Power Supply DC 24V(-) |
| 2               | Power Supply DC 24V(+) |
| 6               | RS485-A                |
| 7               | RS485-B                |
| 3/4/5/8/9       | Reserved               |

### DIP Switch for Baud Rate and Communication Address

DIP 1 is for baud rate setting.

DIP 2 to 6 are for communication address

| DIP Switch                                                    |     |     |     |     |     | Communication address |
|---------------------------------------------------------------|-----|-----|-----|-----|-----|-----------------------|
| 1                                                             | 2   | 3   | 4   | 5   | 6   |                       |
| OFF: Baud rate is<br>1200 bps<br>ON: Baud rate is<br>9600 bps | OFF | OFF | OFF | OFF | OFF | 1                     |
|                                                               | ON  | OFF | OFF | OFF | OFF | 2                     |
|                                                               | OFF | ON  | OFF | OFF | OFF | 3                     |
|                                                               | ON  | ON  | OFF | OFF | OFF | 4                     |
|                                                               | OFF | OFF | ON  | OFF | OFF | 5                     |
|                                                               | .   | .   | .   | .   | .   | .                     |
|                                                               | .   | .   | .   | .   | .   | .                     |
|                                                               | ON  | OFF | ON  | ON  | ON  | 30                    |

## 8 Operating

### 8.1 T300-SA, T300-SV-05, T300-SV-10, T300-SF Operating

1) Make sure the power supply is DC 24V and  $\geq 50W$ .

2) Connect the power supply and necessary control signal wires

Control the pump start/stop with switch signal connected to terminal 6 and 3.

Control the pump direction with switch signal connected to terminal 7 and 3.

Control the pump speed:

For T300-SA: connect 4-20mA signal+ to terminal 5 and signal- to terminal 4.

For T300-SV-05: connect 0-5V signal+ to terminal 5 and signal- to terminal 4.

For T300-SV-10: connect 0-10V signal+ to terminal 5 and signal- to terminal 4.

For T300-SF: connect 0-10kHz signal+ to terminal 8 and signal- to terminal 9.

### 3) Power on the pump and control the pump

Start/stop control: open the switch (terminal 6 and 3 are disconnected) then pump runs, close the switch (terminal 6 and 3 are connected) then pump stops.

Direction control: open the switch (terminal 7 and 3 are disconnected) then pump runs CW, close the switch (terminal 7 and 3 are connected) then pump runs CCW.

Speed control through BCD: set the BCD dial switch at the position according to desired speed.

Speed control through external signal: Set BCD dial switch at "0" position, then input the external signal to control the pump speed. The speed is linearly proportional to the input speed signal.

## 8.2 T300-SC Operating

Connect the power supply and communication wire according to Terminal Instruction (terminal 6 for RS485-A, terminal 7 for RS485-B). Set the baud rate and pump address. Then power on the pump, and send the commands according to Appendix A and B "communication protocol" to control the pump.

## Appendix A Longer OEM Communication Protocol

1. Frame format: 1start + 8data + 1even parity + 1stop, 1200bps or 9600bps
2. Message format: **flag** + **addr** + **len** + **pdu** + **fcs**.

**flag**: E9H, the message head. When sending the message, the data E8H after message head will be replaced with E8H 00H, and E9H after message head will be replaced with E8H 01H.

When receiving the message, the data E8H 00H after message head will be reverted to E8H, and E8H 01H after message head will be reverted to E9H. (Note: if E8 00 replaced E8 or E8 01 replaced E9, E8 00 or E8 01 will be regarded as one byte, no influence on the length of pdu.)

**addr**: one byte, pump address, 1-30.


**len**: one byte, length of pdu.

**fcs**: one byte, XOR of **addr**, **len**, **pdu**.


3. **pdu** format: application layer code format

### 3.1 PC sets pump running parameters

PC sends command:



Pump responds:



- WJ: 2 bytes, using ASCII code, to indicate that this command is used to set pump running parameter. ASCII code of W is 57H, ASCII code of J is 4AH.
- Speed: 2 bytes, hexadecimal number, most significant byte first, resolution is 1rpm. Example: 0096H means 150rpm.
- Full speed and start/stop:
  - Bit0: 1 means pump runs, 0 means pump stops.
  - Bit1: 1 means full speed, 0 means normal speed.
- Direction:
  - Bit0: 1 means CW, 0 means CCW.



Example 1:

To set a pump (addr: 01) to run CW at speed of 150rpm. The message should be:

E9 01 06 57 4A 00 96 01 01 8C

Example 2:

To set a pump (addr: 01) to run CCW at full speed. The message should be:

E9 01 06 57 4A 00 96 03 00 8F

## 3.2 PC reads pump running state

PC calls:

RJ

Pump responds:

RJ

Speed (2bytes)

Full speed and start/stop (1 byte)

Direction (1 byte)

- RJ: 2 bytes, using ASCII code, to indicate that this call is used to read pump running state. ASCII code of R is 52H, ASCII code of J is 4AH.
- Refer to para. 3.1 for instructions of speed, full speed, start/stop, direction

## Appendix B Modbus Communication Protocol

| Parameter          | Address | Data Type | Note                                                                                                                                                                                                                                                                |
|--------------------|---------|-----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Pump speed         | 0x00    | uint_16   | Range: 1-300, corresponding to 1rpm to 300rpm, in increments of 1rpm<br>Example: 1 means 1rpm. 300 means 300rpm.                                                                                                                                                    |
| Full speed running | 0x01    | uint_16   | 1: Pump runs at full speed.<br>0: Pump running state is determined by "Pump speed" and "Start/stop" parameters.<br>Note: "Full speed running" only can be set as 1 when "Start/stop" is 1. When "Full speed running" is 1, "Pump speed" remains previous parameter. |
| Start/stop         | 0x02    | uint_16   | 1: Pump runs at the speed of "Pump Speed"<br>0: Pump stops.                                                                                                                                                                                                         |
| Direction          | 0x03    | uint_16   | 0: pump runs CW<br>1: pump runs CCW                                                                                                                                                                                                                                 |

Note:

- 1 Frame format: 1start+8data+leven parity+1stop
- 2 For 2-byte word data: most significant byte first. For 2- words data: low address first
- 3 Pump only supports function codes of 03 (0x03), 06 (0x06) and 16 (0x10). Reports an error when receives other function code.