


# How to connect with the next filling unit



## Side of the Filling System

- Port:
- A—Power Port
  - B— External Control Input Port
  - C—Connect controller communication Port (H).
  - D— Connect next filling unit Port D when cascade multi filling units.
  - E—Connect controller Power Port (G)